

POL15EM-CC

Installation Sheet

 220-240V



15W LED POLO IP54

ROUND BULKHEAD

CCT CHANGEABLE EMERGENCY

15W CCT Changeable LED POLO MAINTAINED EMERGENCY LUMINAIRE INSTRUCTIONS

These instructions are in addition to the standard luminaire instructions that were supplied with the product you have purchased. Please read them carefully and install the luminaire as per instructions, then keep the instructions for future reference and maintenance.

Important information

It is recommended that luminaires are installed by a qualified electrician ensuring the installation complies to current IEE wiring regulations & local building control.

- These products are designed for connection to a 220-240V mains supply.
- Any broken or damaged parts should be replaced as soon as possible.
- We will not accept responsibility for any claims arising from poor installation.

SAFETY

- Before installation, ensure that the mains supply to the luminaire is switched off and the circuit supply fuses are removed or circuit breaker turned off.
- It is recommended that a qualified electrician is consulted or used for the installation of this luminaire and installed to the current edition of the IEE wiring regulations.
- Check that the total load on the circuit, including this luminaire, does not exceed the rating of the circuit cable, fuse or circuit breaker.

RATINGS

- This luminaire is of class I construction and it requires an earth connection.
- IP54 rated.
- F marked, suitable for installation on normal flammable surfaces.
- Working situation: -20°C to 40°C.
- 220-240V AC rated.
- CE Approved.

INSTALLATION

- Remove the diffuser from the base by turning 45 degrees anti-clockwise and pulling away from the base of the luminaire.
- The gear tray is hinged to allow easy access to the connections. Open the gear tray for access to the cable connections.
- Select a suitable cable entry point provided or by drilling into the base.
- Position and fix the base to a suitable solid surface using screws supplied.
- Enter supply cable into the luminaire ensuring that the hole is smooth or a grommet is fitted.
- Secure the supply cable by way of the cable clamp in the base of the fitting.
- Terminate the cable into the terminal block mounted on the underside of the gear tray ensuring correct polarity is observed and any bare conductors are sleeved.
- **In addition, a secondary permanent live supply should be fed to the luminaire in the 4-pole terminal block**, in the connection marked "L PERM". The permanent supply **MUST** be taken from the same phase as the switch live supply and **MUST** be wired so that upon test, it is isolated at the same time as the switch supply.
- Connect the battery supply to the module by joining the connectors, ensuring correct polarity is observed.
- The green LED fitted to the luminaire should be on after reconnecting the power supply, indicating that the batteries are charging.
- The batteries should be charged for at least 24 hours before carrying out a full discharge test to check if the maintained duration is being achieved.
- Select the required CCT by sliding the switch on the front face of the gear tray to the allocated colour (4000K-5000K).
- Close the hinged gear tray.
- Re-fit the diffuser by placing over the base and turning clockwise until it locks into position.

To change the decorative trim around the diffuser, push the polycarbonate diffuser inwards over the retaining lugs, to refit push diffuser into the replaced bezel over the fixing lugs.

OPERATION / MAINTENANCE

1. Nominal battery life is 4 years, after which time they should be replaced with a suitable equivalent.
2. When the lamp operates from the battery supply it will be at a reduced light level.
3. Keep the luminaire clean so it will not affect performance.

OPERATIONS CHECK

Periodic testing should be carried out monthly by simulating a failure of supply, causing the fitting to be energised from its battery. Interruption of the supply should be carried out by the operation of a local key switch or other isolation device. During this period all fittings should be examined visually to ensure that they are functioning correctly. At the end of the test period the supply should be restored and all indicator lamps or devices checked to ensure that the normal supply has been restored.

The duration of the simulated failure should be:

Each month: Isolate the power supply and check the light is illuminated. This test should last for no more than 45 minutes. Complete the test record form supplied.

Once each year: Isolate the power supply and check that the light is still illuminated after 3 hours. Complete the test record form.

INSTALLATION, MAINTENANCE AND OPERATION CHECK RECORD

Location:

Installation Date:

Installation Test Duration:

Installed By:

Month	Test	Year:		Year:		Year:		Year:		Year:	
		Sign	Date	Sign	Date	Sign	Date	Sign	Date	Sign	Date
1	Short										
2	Short										
3	Short										
4	Short										
5	Short										
6	Short										
7	Short										
8	Short										
9	Short										
10	Short										
11	Short										
12	3 hr Endurance										