LKCL18-CCT-MW




Installation Sheet

SLIM LED POLO



IP54 Round Bulkhead CCT Changeable / Tri Wattage 9W/14W/18W c/w MICROWAVE SENSOR











These instructions should be read carefully and retained after installation for further reference and maintenance.

SAFETY

- Before installation, ensure that the mains supply to the luminaire is switched off and the circuit supply fuses are removed or circuit breaker turned off
- It is recommended that a qualified electrician is consulted or used for the installation of this luminaire and installed to the current edition of the IEE wiring regulations
- Check that the total load on the circuit, including this luminaire, does not exceed the rating of the circuit cable, fuse or circuit breaker

RATINGS

- This luminaire is of Class II construction and it does not require an earth connection
- IP54 rated
- F marked, suitable for installation on normal flammable surfaces
- Working situation: -20°C to 40°C
- 220-240V AC rated
- UKCA, CE Approved

DIMENSIONS:

Ø315mm 80mm 170mm 35.5mm


CCT & POWER ADJUSTABLE:

Switch off the mains supply before changing power or CCT Use the driver switch to change the power 18W 14W HTH H II

Use the LED gear tray switch

to change the CCT temperature

WIRING DIAGRAM:



TECHNICAL SPECIFICATIONS:

- Input Voltage: 220-240V/AC
- Tri-Power Selectable: 9W / 14W / 18W
- Light Output: 9W 900lm

14W - 1450lm 18W - 1850lm

CCT Changeable (switch):


3000K/4000K/6500K

- CRI > 80
- IP Rating: IP54


- Microwave sensor included
- Hold Time: 5s 30min (set via 3 DIP switch)
- Sensitivity: 100% 10% (set via 3 DIP switch)
- Daylight Sensor: 2lux 50lux / Disable (set via 3 DIP switch)
- Protection Class: Class II
- Housing: PC Body & Diffuser
- Operating Temp.: -15°C to +40°C
- Dimensions: Diameter 315mm / depth 80mm
- Warranty: 5 years


INSTALLATION INSTRUCTIONS:


▲ Switch off the mains supply before installation.




1. Choose a suitable flat installation position.











that the hole is smooth or a grommet is fitted and connect it to the terminal block (see wiring instructions).





7. Re-fit the diffuser by placing it over the base and lock into position using the screws.

